



INSTRUCTIONS FOR GUL ANALOGUE WATCHES

INSTRUCTION FOR GUL ANALOGUE WATCHES

Functions: Analogue time.

Setting the time: Pull out the crown and adjust the hands to correct time

INSTRUCTION FOR GUL ANALOGUE WATCHES WITH DATE OR DAY/DATE

Functions: Analogue time, date or day/date.

Setting the time: Pull the crown all the way out. Adjust the hands to correct time. **DIVE:** Untighten the crown, which is screwed down, then pull it all the way out. Be sure to tighten the screw-in crown firmly after the adjustment!

Setting the date: Pull the crown halfway out. Adjust to correct date. Day of week is set by turning crown in reverse direction. **DIVE:** Untighten the crown, which is screwed down, then pull it halfway out. Adjust the date. Be sure to tighten the screw-in crown firmly after the adjustment!

Advance the hands 12 hours if the date shifts at 12 AM.

GENERAL:

Battery: Normal lifetime is 1.5 years, depending on how often the alarm function is used, if available. A watch specialist must change the battery.

Water resistance: 10 ATM (all water sports except for diving).

Water resistance DIVE: 20 ATM (all water sports incl. diving).

DELVA AB - LUND - SWEDEN

Mail: guldelva.se

FAX +46 46 126343

Internet: <http://www.gulwatches.com>