



ENVOY



AUTHORITY22®

Select Machine

Pattern Information

Date:

Pattern Type:

Pattern Difficulty:

Pattern Designer:

Pattern Volume (ml):

Surface Information

Surface Type:

Surface Brand:

Age:

Pattern Parameters

Pattern Number:

Pattern Name:

Mode:

Forward Speed:

Start Cleaner Spray:

Start Squeegee:

Start Oiling:

Split Pattern:

Supplies Information

Lane Cleaner:

Cleaner Mixture Ratio:

Cleaner Transition Distance:

Cleaner Spray End Distance: Envoy

Lane Conditioner:

Notes: _____

Zone	1	2	3	4	5	6	7	8
Zone End Distance	10	18	26	32	41			
Zone Ratio L	2,7 : 1	3,3 : 1	3,0 : 1	4,5 : 1	1,0 : 1	### : 1	### : 1	### : 1
Zone Ratio R	2,7 : 1	3,3 : 1	3,3 : 1	6,3 : 1	1,0 : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	10,81	5,99	4,68	1,77	0,00	0,00	0,00	0,00

ZONE	7 Pin Side																	Board Number																	10 Pin Side																
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1												
1	25	25	25	25	30	35	55	65	75	80	80	80	80	80	85	90	95	95	95	95	95	95	95	95	95	95	90	85	80	75	65	55	35	30	25	25	25	25	25												
2	15	16	17	18	19	20	30	45	50	55	55	55	55	55	55	55	65	70	70	70	70	70	70	70	70	70	70	65	55	50	45	30	20	19	18	17	16	15													
3	14	15	16	17	18	19	20	25	35	40	42	45	45	45	45	45	50	55	55	55	55	55	55	55	55	55	55	50	45	40	25	18	17	16	15	14	13	12													
4	6	6	6	6	6	8	9	11	13	15	17	18	20	22	24	26	28	30	32	32	32	32	32	32	32	32	32	32	32	26	20	17	15	7	5	5	4	4	4	4											
5	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1												
6																																																			
7																																																			
8																																																			

