


RAKET 60 VARAOSALUETTELO



RAKET 60 VARAOSALUETTELO



3075 String lock



3115-1 Oil sealing, teflon. 15 x 26 x 7



3135 Magnapull spring -06 for alu. cover



33117 Flywheel hub 120, 85, 60



33131 Shaft stringdisc 07-



33132 O-Ring shaft for string disc



33134-1 String disc aluminum 11-



33135 Magnapull spring 07-



33136 Friction ring aluminum



33138 Start string



33153 Start boss

RAKET 60 VARAOSALUETTELO



[4049 Air filter cover, Raket 60](#)



[4049-1 Airfilter 60](#)



[4053 Exhaust gasket, Raket 60](#)



[4060 Stud 5x55](#)



[4060-1 Nut 5x25](#)



[4061 Sprocket guard, Raket 60](#)



[4065 Inlet flange, Raket 60](#)



[4066 Inlet gasket, Raket 60](#)



[4076-1 Ignition system restricted 9800 rpm](#)



[4085 Cylinder cpl. 0,50 Raket 60](#)



[4086 Piston ring, Raket 60](#)

RAKET 60 VARAOSALUETTELO



4087 Piston cpl. Raket 60



4090 Cylinder gasket. Raket 60



4091 Small end bearing. Raket 60



4092 Crank shaft. Raket 60



4093 Main bearing. 6202 TN9c3




4117 Flywheel 60 06-



4118 Fly wheel nut. Raket M10 x 1. 60, 95, 120



4119 Washer flywheel nut 60, 95, 120



4120 Cone for clutch 60



4126 Cylinder cover. Raket 60



4127 Exhaust flange. Raket 60

RAKET 60 VARAOSALUETTELO



[4137 Start coat, Raket 60 plastic](#)



[41391 Start unit, cpl, Raket 60 plastic](#)



[41401 Silencer R60 kit](#)



[4140-1 Box silencer, Raket 60 catalytic](#)



[4143 Clutch, Raket 60](#)



[4143-3 Clutch shoe 60](#)



[4144 Clutch drum, Raket 60](#)



[4146 Circlip for clutch, Raket 60](#)



[4147 Needle bearing for clutch, Raket 60](#)



[4148 Washer 12x18, Raket 60](#)



[4149 Nut for clutch, Raket 60](#)

RAKET 60 VARAOSALUETTELO



4150 Crank case, Raket 60 left



4151 Crank case gasket, Raket 60



4177 Ignition cover, Raket 60